



ALL1681211v2

1200 Mbit Powerline with Smartlink + WiFi



USER MANUAL

Installation

Plug the devices directly into the wall socket.

Please do not use a surge protector or a multiple socket strip, as these may cause interference.



Connecting the Powerline Adapter

1. Plug the network cable into the ETH port of the powerline adapter.
2. Connect the other end of the cable to the router/end client.
3. Plug the powerline adapter into the wall outlet.

Attention:



If possible, avoid direct sunlight. This could cause the device to overheat.

The Powerline adapter is suitable for indoor use only and is not certified for outdoor use.



Note! To disable the WLAN press the WiFi button for 6-10 seconds

LEDs

LED	STATE	DESCRIPTION
 PWR	ON	POWER on
	OFF	POWER off
 PLC	ON	Powerline link active
	Blinking	Powerline Pairing
	OFF	No powerline link
 WiFi	ON	WIFI on
	OFF	WIFI off

Build a private network with 2 adapters

- Press the Pair button for 1-3 seconds at the first adapter (A). The PLC LED starts to flash.
- The pair button must also be pressed on adapter B within the next 30 seconds. The PLC LED starts to flash there as well.
- After a short time, the PLC LEDs on both adapters should light up continuously.

The configuration is now complete.

Build a private network with multiple adapters

- Plug the adapters into a power strip near your PC.
- Install the [Powerline Utility](#), which you can download with the QR code.



- After installation, connect your PC directly to one of the powerline.
- Start the software.
- The private network name can be changed here if necessary, but must be the same on every device.
- This procedure must also be performed for the other powerlines.

The configuration is now complete. You can now install the devices at their place of use.

WLAN Setup

1. Establish a connection to the device

To call up the web interface of the ALL1681211v2, please start your web browser. The default values are:

IP address: 192.168.2.1

User & Password: admin

Give your PC/computer an IP address from the subnet 192.168.2.X (X = 2-254) and the subnet mask 255.255.255.0.

Start your Internet browser, type 192.168.2.1 into the address field and confirm with "Enter".

Log in to the login screen with admin as user and password.

2. WLAN settings

Navigate to Network > WLAN. Here you can adjust your WLAN settings.

- Click on "Edit" to adjust the corresponding WLAN.
- Under WLAN network configuration, you can adjust the SSID (name of the WLAN) and the WLAN encryption.
- Once you have entered the desired values, you must confirm them with the "Save" button.

Safety Instructions

Please be sure to observe the following instructions:

General notes



RISK

- Only use the device for the purpose it was designed.
- Only use the device as described in the Quick Start Guide or manual.
- Any other use is considered improper and may result in property damage.
- Neither ALLNET® nor the dealer accepts liability for damage caused by improper or incorrect use.
- All safety instructions must be read through.
- The manual should be kept for future reference.

Mounting instructions



WARNING

- NEVER place the device near radiators, air conditioners or water sources. This greatly increases the risk of electric shocks, short circuits or fire.
- The humidity should be between 20% and 80%, otherwise condensation may occur.
- Protect the device from direct sunlight, extreme heat, open fire and dust. Otherwise, the risk of electric shocks, short circuits or fire increases.
- Never place the device on surfaces that are sensitive to heat.
- Do not use the device in damp rooms and under no circumstances in potentially explosive areas.
- The device is designed for use in enclosed spaces.

Operating notes

ATTENTION

- Operate the device only with the voltage indicated on the device or on the included power supply unit.
- Any batteries present are only to be replaced with the same or an equivalent type.
- Do not use obviously defective devices. If the unit does not operate normally – especially if unusual odors or noises occur – unplug the power cord from the socket immediately.
- Never expose the device to direct sunlight during operation.
- Never operate the device near sources of heat.
- Protect the device from moisture, dust, liquids and vapors.
- Never open the device.
- Work on the device may only be carried out when the device has been disconnected from its power source.
- The device may only be operated by persons who have read the instructions or have been instructed in its operation by a competent person.

Instructions for repair and maintenance.



RISK

- Repairs may only be carried out by trained, authorized personnel.
- Regular maintenance is not necessary.
- Never open the device.
- For cleaning work, disconnect the device from its power source.
- Do not use any cleaning agents containing solvents for cleaning, but only a soft, dry antistatic cloth.
- It is forbidden to make any modifications to the unit.
- Damaged devices or damaged components may no longer be used.



NOTE

ALLNET GmbH Computersysteme declares that the device **ALL1681211v2** is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU. The Declaration of conformity can be found under this link: <http://ce.allnet.de>

ALLNET GmbH Computersysteme
Maistrasse 2
82110 Germering

Tel.: +49 (0)89 894 222 - 22
Fax: +49 (0)89 894 222 - 33
Email: info@allnet.de



CE Marking is the symbol as shown above. The letters "CE" are the abbreviation of the French phrase "Conformity European" which literally means "European Conformity". The terms initial use was as the "EC Mark". With the Directive 93/68/EEC from 1993 it was officially replaced by the "CE Marking". Nowadays the "CE Marking" is used in all EU official documents.



NOTE



This symbol on the product or on its packaging indicate that this product is not to be disposed with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of electrical waste or electronic equipment. The separate collection and recycling of your waste equipment will

DE13101093 help to conserve natural resources and ensure that it is recycled in a manner that protects human health and environment. For more information about where you can dispose your waste equipment, please contact your local city office, your household disposal service or the shop where you purchased the product.



This recycle logo indicates that this product can be recycled, not that the product has been recycled. It is possible that this device will not be accepted in all recycling collection systems.



The recycling codes are used to guarantee the correct handling of waste. It is an internationally recognized classification that assigns a unique number to each waste material. This number provides information on how the waste material can best be recycled to ensure the least possible impact on the environment. The code PAP 22 describes these instructions for the device, which were printed on paper. They should be disposed of through the usual recycling channels, such as waste paper collection points.



The RoHS directive aims to restrict certain dangerous substances commonly used in electronic and electronic equipment. This RoHS compliant symbol indicate the component is tested for the presence of Lead (Pb), Cadmium (Cd), Mercury (Hg), Hexavalent chromium (Hex-Cr), Polybrominated biphenyls (PBB), and Polybrominated diphenyl ethers (PBDE). For Cadmium and Hexavalent chromium, there must be less than 0.01% of the substance by weight at raw homogeneous materials level. For Lead, PBB, and PBDE, there must be no more than 0.1% of the material, when calculated by weight at raw homogeneous materials. Any RoHS compliant component must not have more than 100 ppm of mercury and the mercury must not have been intentionally added to the component.